


TTS-2 Tabletop Stand, Side Support Instructions

Parts: Oval Base
Small Peg with screw & washer
Rubber O-ring

Note: If a part of this stand is missing or broken when received, please contact customer support via email at customerservice@advancedsalestech.com. Parts will be promptly replaced if we are notified within 10 days of receipt.

To Assemble:

1. Remove peg, screw & washer from the enclosed package. Insert screw through the washer and then through the bottom of the selected hole in the oval base.
2. Attach peg to the screw and tighten securely. A rubber o-ring has been provided to increase stability, if needed, when positioning the inflatable display form on the peg. Position the o-ring over the peg near the top of the peg. Slide display form over the peg until firmly seated.



Using the Stand:

The TTS2 stand, although usable for other purposes, is designed for use with Inflatable Mannequin Products such as: Inflatable $\frac{3}{4}$ Forms and Inflatable Panty/Brief Forms.

Warning: Warranty and return claims are void if stand is damaged when used for purposes other than those for which it is designed.

Copyright 2004-2011 Advanced Sales Technologies, LLC